



ASSEMBLY INSTRUCTION

R.B.S. BED

With Flat Fitting And Slats

First of all, correctly spread out all of the pieces you are about to put together.

Step 1: Fitting SIDE RAILS

Place the headboard against the wall to perform this step.

- Ensure **the metal brackets** on the headboard and footboard are **square** to the side rail brackets prior to putting each side rail in photo A and B.

(note: do not lock one side of a side rail in too firmly).

Then, push down with your foot gently to complete (photo C).



A



B



C

Step 2: Fitting THE CENTER LEG

It is important to do this step correctly

- **Remove the centre leg extension** from its packaging, and **slide** it onto the **centre leg**.



R.B.S. BED With Flat Fitting And Slats

- Fit and tighten the nut and bolt at **the first hole up from the ground.**



Step 3: Fitting THE CENTER RAIL

- Extend the centre rail, and fit to the headboard and footboard.



- Then fit and tighten **the extension rail's lock bolt.**



R.B.S. BED **With Flat Fitting And Slats**

Step 4: Adjusting THE CENTER RAIL FOOT

- Unscrew the rubber foot under the centre rail leg until it touches the ground



- Turn the nut clockwise to bring it up to the end of the extension leg, then tighten it.



Step 5: Fitting SLATS

When fitting the slats into the side rails, ensure they fit firmly into their positions



R.B.S. BED **With Flat Fitting And Slats**

The assembly is now completed. The mattress can go on top of the slats.



This assembly instruction is also available in video format.
To view it, please visit our website www.pgt-reclaimed.com

Care tips:

- Every few months, turn the mattress over to the other side, and
- Readjust the slats to ensure they didn't move out of their slots, and
- Re-screw the nut of the center leg to have it firm complete.

ENJOY YOUR NEW P.G.T. RECLAIMED[®] PRODUCT